

CF58

Yamaha MT07

| Fitting kit for the left side | | | |
|-------------------------------|--------------------|------------|-----|
| ID | Description | Cat.no. | Pcs |
| 1 | Crash frame | | 1 |
| 2 | Screw M12x120x1.25 | 913 | 1 |
| 3 | protector | PVPMN-0/12 | 1 |

| Fitting kit for the right side | | | |
|--------------------------------|--------------------|------------|-----|
| ID | Description | Cat.no. | Pcs |
| 1 | Crash frame | | 1 |
| 2 | Screw M12x120x1.25 | 913 | 1 |
| 3 | protector | PVPMN-0/12 | 1 |

We recommend to use glue on all threads (medium strong).

Instructions (for both sides):

- 1.) Remove original screw from upper part of frame.
- 2.) Prepare protector and screw.
- 3.) Attach upper part of frame using screw M12 (ID2) with protector (do not tighten it completely).
- 4.) Remove original screw from lower part of frame.
- 5.) Attach lower part of frame using this original screw.
- 6.) Tighten both screws.



